

# **Impedance Settings: Nomad / Belair212**



**Rev A  
11/8/2008**

***CARVIN***  
**carvinservice.com**

## Impedance switch



Why the Impedance switch is so important: -Circled in red-, the impedance switch is connected to the output transformer and the Power tubes, if improperly set damage to the tubes or damage to the amp can result.



How to adjust: Use a flathead screw driver to move up or down, it has 3 settings: 4, 8, 16 ohms.

## Belair + 212E



**Set impedance switch to 4**

## Belair + 112E



**Set impedance switch to 4**

## Nomad + 112E



**Set impedance switch to 4**

## Nomad + 212E



**Set impedance switch to 4**

Belair



**Set impedance switch to 8**

Nomad



**Set impedance switch to 8**

s

-Out put 1 and 2 on the Nomad and Belair212 are in parallel.